60% PRELIMINARY PLANS

ALL INFORMATION CONTAINED WITHIN

IS TO BE CONSIDERED PRELIMINARY

NOT FOR CONSTRUCTION



Cast-in-Place Balanced Cantilever Construction




Reggie Walden, P. E.

- Position
- Experience / Work History
- Current Assignment ARB



Agenda

- Discussion
 - Balanced Cantilever Construction
 - Similar Successful Projects
 - Allegheny River Bridge
- Questions / Working Session




Similar Successful Projects - FIGG

- Smart Road Bridge Blacksburg, VA
- Wabasha Freedom Bridge St. Paul, Mn
- Allegheny River Bridge Pittsburgh, PA



Smart Road Bridge


Blacksburg, Virginia



Smart Road Bridge

Blacksburg, Virginia

- 5 Spans (284',472', 472', 472', 284')
- Girder Depth (31' at Piers, 12' at Midspan)
- Typical Segment Length 16 feet




Smart Road Bridge

Blacksburg, Virginia



- 39' Wide
- 167' Tall Hollow Piers w/ Inlayed Stone



Wabasha Freedom Bridge


St. Paul, Minnesota



Wabasha Freedom Bridge

St. Paul, Minnesota

- 4 Spans (230', 392', 392', 230')
- Girder Depth (20' at Piers, 8' at Midspan)
- Typical Segment Length 16 feet
- Twin Wall Diaphragms & Piers




Wabasha Freedom Bridge

St. Paul, Minnesota

Twin Structures

 Single Cell Box (each)

48' Wide (each)



Allegheny River Bridge

Pittsburgh, Pennsylvania



Allegheny River Bridge

Pittsburgh, Pennsylvania


- 6 Spans (285, 380, 380, 444, 532, 329)
- Girder Depth (19' & 25' at Piers, 11' at Midspan)
- Typical Segment Length 16 Feet
- Twin Wall Diaphragms & Piers



Allegheny River Bridge


Pittsburgh, Pennsylvania

- TwinStructures
- Single Cell Box (each)
- Variable Width 61' -73'







Basic Casting Procedure




Cast Pier Table




Stress Pier Table Cantilever Tendons




Assemble Traveler A




Assemble Traveler A




Assemble Traveler A





Cast Segment 1




Stress Cantilever Tendon












Install Traveler B




Install Traveler B




Install Traveler B





Cast Segment 2




Stress Cantilever Tendon









Cast Segment 3




Stress Cantilever Tendon








Launch Traveler A



Cast Segment 4











Cast in Stages


Typical Duration: 30 Days









Launching Rails



Overhead Trusses



Bottom Form Deck






Typical Duration

– 5 Weeks 1st Cantilever

– 3 WeeksSubsequent Cantilevers

"Learning Curve"






- 7. Final Set-Up Survey
- 8. Place Concrete

- Align Bottom Deck & Outer Web Forms
- 2. Bottom & Web Bulkhead Forms






- 9. As-Cast Survey
- 10. Cure Segment


- 3. Bottom Slab & Web Rebar & Ducts
- 4. Advance Core Form
- 5. Top Slab Bulkhead Forms






- 11. Stress Tendons
- 12. Release Traveler
- 13. Advance Traveler

6. Top Slab Rebar & Ducts






- Align Bottom Deck & Outer Web Forms
- 2. Bottom & Web Bulkhead Forms

- 7. Final Set-Up Survey
- 8. Place Concrete







- 3. Bottom Slab & Web Rebar& Ducts
- 4. Advance Core Form
- 5. Top Slab Bulkhead Forms

- 9. As-Cast Survey
- 10. Cure Segment







- 7. Final Set-Up Survey
- 8. Place Concrete

- 1. Align Bottom Deck & Outer Web Forms
- 2. Bottom & Web Bulkhead Forms



Typical Casting Cycle Duration

- Casting Cycle Durations
 - 7-10 Days / Segment 1st Cantilever
 - 5 Days / Segment Subsequent
- Two or More Form Travelers



Casting Cycle Duration

Wabasha Freedom Bridge

- Normal Weather
 - 8 Segments in 6 Days (.75/day)
- Cold Weather
 - 4 Segments in 5 Days (1.25/day)

2 Sets of Travelers






- Pier Table Construction
 - Up to 33% of Total Cantilever Duration
- Form Traveler Installation
 - Typically 3 Weeks Per Traveler
- Number of Form Travelers
 - More Travelers Can Increase Efficiency



- Length of Cantilevers
 - More Segments Increases Efficiency
 - Impact of Pier Table and Traveler
 Installation Reduced
- Effect of "Learning Curve"
 - 1st Cantilever Up To 2 x Typical Duration





Piers



Pier Tables



Traveler Assembly



Traveler Assembly



Overhead Truss "Horse" And Bottom Deck Form



Launching Rails
And Core Form



Traveler Assembly



Concrete Placement



Cantilever Construction











Forming Closure


Closure Segment

Completed Closure




Equipment on Deck






Wabasha Freedom Bridge



Pier Table




Pier Table




Form Traveler Installation



Completed Travelers



Cantilever Construction



Stressing Tendons







Foundations




Piers









Traveler Assembly







Cantilever Construction



